

Directions for

* Paper Welder


Keep this Folder

Read Carefully

This appliance is precision built, carefully inspected and tested before leaving our plant, and, unless misused, should last indefinitely.

OPERATION—Papers are inserted in the throat as far as possible.

A single weld may be made diagonally across a corner. It is preferable to use two welds horizontally across the top of the paper.



DO NOT STRIKE but press handle down with the palm of the hand as far as it will go. It costs nothing to push down the handle, therefore the more welds the more securely the paper will be held.

The Paper Welder has been designed for general office use and is not recommended for some of the poorer quality paper. Should dies become clogged remove pivot pin with rubber end of lead pencil and clean both top and bottom dies with needle or pin.

LUBRICATION — A little grease or vaseline once in a while on steel pressure pad under the cam of the handle will suffice. **DO NOT USE OIL.**

SEPARATING WELDS — Sheets that have been welded together may be separated without mutilating the paper. Lay papers on desk or hard surface, rub round or smooth object over the weld with pressure, which will flatten weld enabling the papers to be separated readily.

Paper Welder, Inc.

• Medina, New York